

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER — To reduce the risk of electrocution:

1. Always unplug this appliance immediately after using.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. Do not reach for an appliance that has fallen into water or other liquid. Unplug immediately.

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. This product is not to be used by, on, or near children or by individuals with certain disabilities.
3. Use this appliance only for its intended purpose as described in the manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a

damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service centre for examination and repair.

5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. To avoid burning, do not pick up the unit while water is hot since water can spill out.
7. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and other debris.
8. Never use while sleeping.
9. Never drop or insert any object into any opening or hose.
10. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
11. Do not use an extension cord with this appliance.
12. Unplug this appliance before filling. Fill reservoir with tap water only. Do not overfill.
13. Use The Skin Care Facial Spa only on a level surface.
14. Do not use additives.
15. Never place face close to facial steamer in one position as this may cause scalding.
16. To avoid burning, do not touch after plugging in water reservoir unit.
17. Do not mix old and new batteries. Do

not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries.

18. Do not use the spa without the mask.
19. Do not place hand in the base.
20. Do not touch steam as it comes out of the base.
21. Use tap water only. Do not use additives.
22. Do not move or pick up the unit until the water cools.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.



• The Skin Care unit operates on 2 “AA” batteries. For battery insertion, gently pull down lower cap and insert batteries.

If you have any skin condition, sensitivity to heat or other health issues or questions, including those relating to use of this product while undergoing any treatments or taking any medications, please consult with a physician before use.

INSTRUCTIONS FOR USING YOUR SKIN CARE FACIAL SAUNA.

Before beginning, cleanse your face, following your daily care routine. Lightly pat your favourite moisturizer or eye cream around the eye area.

- Place the facial spa on a dry, level surface.
- Lift facial mask away from base.
- Fill the water cylinder with warm tap water. Pour water into the reservoir (see Figure 1) and plug it into a 120 volt A.C. household outlet. Turn switch to “ON” position.
- Place facial mask over unit. (see Figure 2) Lock the facial mask in place.



Figure 1



Figure 2

NOTE: One fill provides between 10-30 minutes of soothing mist. If the facial spa should run out of water, shut off immediately, then begin your facial again.

- Clean your face and neck
- Allow approximately 3 to 4 minutes for steam mist to develop, then place your face gently against the rim of the facial mask. To avoid burning, do not pick up the unit while water is hot since water will spill out.
- If more steam is desired, place a towel over your head that so it covers the mask and sides of the steamer.
- Close your eyes and relax as the soothing mist begins deep cleansing action.
- Remove your face occasionally and blot with a cool, damp towel. Steam for a minimum of 5 minutes, but no longer than 30 minutes.

- Immediately after steaming, rinse your face with cool water.

INSTRUCTIONS FOR USING YOUR SKIN CARE TOOL

- Snap the exfoliating brush attachment onto the unit, making sure it is securely attached.
- Apply a generous amount of your favourite exfoliating cream to your face.
- At the speed of your choice with the exfoliating brush attachment, massage the cleanser on your face in a circular motion, making sure not to exceed two minutes.
- Use for 10 second intervals per area beginning with the forehead; avoiding the eye area, move downwards toward the cheek and nose area then to your chin area. This step exfoliates, thoroughly cleans and removes dulled skin cells. Rinse face and pat dry. Next apply cool water or your favourite astringent to close pores and seal in moisture.
- Now you are ready to apply your favourite moisturizing lotion by using the sponge applicator. Dot your forehead, cheeks, nose and chin with a generous amount of moisturizer and smooth the cream into your skin. Apply light to medium pressure and use upward, circular strokes. After just one personal facial with the Skin Care Facial Spa you'll find your skin looking fresher and healthier.

SPECIAL PAMPERING TIPS FOR DELICATE AREAS

THE EYE AREA

- Give special care to the eye area during your personal facial, by lightly massaging additional moisturizer or eye cream on eyelids and under your eyes before you begin.

THE NECK & THROAT

- Apply your favourite moisturizer to your entire face.
- Mist your face for only 5 minutes, following Instructions For “Your Personal Facial”.
- Tilt your head backward so your throat is approximately 2 inches from the facial mask.
- Mist your throat for 2 minutes. For best results, accelerate moisturizing process by gently turning neck from side to side.

SPECIAL USES

- Consult your physician or dermatologist for instructions on how to best use The Skin Care Facial Spa for your specific condition.

USER MAINTENANCE INSTRUCTIONS

Caring for The Skin Care Facial Spa After Completing Your Facial:

- Always turn off and unplug The Skin Care Facial Spa from the electrical outlet before cleaning.
- Let cool then empty excess water, and wipe dry interior of the facial mask and rim around the opening.
- Wipe the base with a clean, damp cloth, then polish lightly with a dry one. NEVER IMMERSE THE FACIAL SAUNA IN WATER.
- Do not attempt to repair the appliance yourself. Return to the place of purchase with sales receipt.
- Facial sponge and brush attachments should be cleaned after each use by running them under warm water. Rinse thoroughly and squeeze out any excess water. Allow attachments to air dry thoroughly before reusing. Clean the Skin Care unit with a dry cloth only. Do not immerse in water.

CAUTION

Never allow the power supply cord to be pulled, twisted or severely bent. Never wrap the cord tightly around the unit, causing it to rupture and short circuit. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**


If cord or unit is damaged or does not operate properly, return it for repair to an authorized Conair Service representative only. No repairs should be attempted by the consumer. The Skin Care Facial Spa is for household use only.

STORAGE- IMPORTANT

When not in use, your unit should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around unit. Allow the cord to hang or lie loose and straight at the point of entry into the unit.

**WARNING:
IF YOU THINK THE
POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically alive even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

Public Service Ad from Association of Home Appliance
Manufacturers and Underwriters Laboratories, Inc.

LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below that is nearest you, together with your purchase receipt and \$7.50 for postage and handling. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

SERVICE CENTRE:

Conair Consumer Products Inc.
100 Conair Parkway,
Woodbridge, Ontario. L4H 0L2
1-800-472-7606

Consumer Call Centre E-mail:
Consumer_Canada@Conair.com
www.conaircanada.ca

©2007 CONAIR CONSUMER PRODUCTS INC.

06CN1437

IB-7328

MOISTURIZING MIST
SKIN CARE SYSTEM



Instruction Booklet

For your safety & continued enjoyment of this product, always read the instruction book carefully before using.

Model MDF1RC

CONAIR