

IMPORTANT SAFETY INSTRUCTIONS

When using your iron, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

DANGER — Any appliance is electrically live even when the switch is off.

To reduce the risk of death by electric shock:

1. Use iron only for its intended use.
2. To protect against a risk of electric shock, do not immerse the iron in water or other liquid.
3. The iron should always be turned off before plugging in or unplugging from an outlet. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
4. Do not allow cord to touch hot surfaces.
5. Let iron cool completely before putting away.
6. Loop cord loosely around iron when storing.
7. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or is dropped or damaged in any manner.
8. If the product requires attention within the warranty period, call the toll-free number listed in the warranty section of this manual for information on examination, repair, or electrical or mechanical adjustment.
9. To avoid the risk of electric shock, do not disassemble the iron; instead, take it to an authorized service center for examination and repair. Incorrect reassembly can cause

risk of electric shock when the iron is used.

10. This appliance should not be used by or near children or individuals with certain disabilities.
11. Do not leave iron unattended while connected or on an ironing board.
12. Close supervision is required for any appliance used by or near children.
13. Always position iron carefully to prevent it from falling if ironing board is accidentally moved or cord is pulled. Always use heel rest.
14. Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
15. If you need to clean the iron, unplug and allow to cool. Use a slightly damp cloth and wipe down the outside of the iron. Do not use cleaning agents or place the iron in water or cleaning fluids.
16. Do not operate in the presence of explosive and/or flammable fumes.
17. Do not use iron outdoors.
18. This product is for household use only, not for commercial or industrial use.
19. **Always unplug appliance immediately after using.**
20. Always disconnect iron from electrical outlet when filling with water or emptying and when not in use.
21. Use this appliance only for its intended use, as described in this manual.

INSTRUCTIONS

To avoid circuit overload, do not operate another high-wattage appliance on the same circuit. If an extension cord is absolutely necessary, a 15-ampere rated cord with a polarized plug and CUL, CSA or NOM approval should be used. Cords rated for less amperage can result in risk of fire or electric shock due to overheating. Care should be taken to arrange the cord so that it cannot be pulled on or tripped over.

SAVE THESE INSTRUCTIONS

DO NOT let children or untrained persons use the appliance without supervision.

NEVER immerse the iron, cable or plug in any liquid.

DO NOT leave the hot iron touching fabrics or very inflammable surfaces.

DO NOT leave the appliance unnecessarily plugged in. Disconnect the plug from

the mains when the appliance is not being used.

NEVER touch the appliance with wet or damp hands.

DO NOT use the power cord or the appliance in order to pull the plug out of the socket.

DO NOT leave the appliance exposed to the weather (rain, sun, etc.).

DO NOT leave the iron without supervision when it is connected to the power supply.

DO NOT fill the reservoir with water before removing the plug from the socket.

PLEASE NOTE!

Do not use chemical additive, scented substances or decalcifiers. Failure to comply with the above-mentioned regulations leads to the loss of guarantee.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other).

As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature. Please be sure to read the following instructions carefully before you use your iron for the first time. Once you have familiarized yourself with this appliance, please save this instruction manual for future reference.





OPERATING INSTRUCTIONS

PREPARING FOR FIRST USE

Before first use, remove all labels from the soleplate and housing. Turn the iron on, allow to heat up, then turn the iron off.

Sort the laundry to be ironed according to the international symbols on the garment label, or if this is missing, according to the type of fabric.

l. The tank can be filled with ordinary tap water.

GARMENT LABEL	FABRIC TYPE	THERMOSTAT REGULATION
	synthetic	• low temperature
	silk - wool	•• medium temperature
	Cotton - linen	••• high temperature
	Fabric not to be ironed	

a. Using a clean measuring cup, slowly fill the tank until the water reaches the Max indicator.
DO NOT OVERFILL.

b. Wipe off any water that may have spilled on the outside of the iron with a soft clean cloth.

2. Set the iron on a stable, flat surface. We recommend using a quality ironing board as the pressing surface. Be sure to give yourself enough room to maneuver the iron when pressing.
3. Plug the iron into a receptacle. Make sure that no other high-wattage appliances are plugged into the same circuit.
4. Once the iron heats up, it is ready to use.
5. After use, let the iron cool for 10 minutes before putting it away.

GENERAL INSTRUCTIONS

When using the iron for the first time, you may notice a slight emission of smoke and hear some sounds made by the expanding plastics. This is quite normal and it stops after a short time. We also recommend passing the iron over an ordinary cloth before using it for the first time.

ANTI-CALC SYSTEM

A special resin filter inside the water reservoir softens the water and prevents scale build-up in the plate. The resin filter is permanent and does not need replacing.

Please note:

Use tap water only. Distilled and/ demineralised water makes the “Zero-Calc” anti-calc system ineffective

by altering its physicochemical characteristics.

DO NOT use chemical additives, scented substances or decalcifiers. Failure to comply with the above-mentioned regulations leads to the loss of guarantee.

ANTI-DRIP SYSTEM

With the anti-drip system, you can perfectly iron even the most delicate fabrics.

Always iron these fabrics at low temperatures.

The plate may cool down to the point where no more steam comes out, but rather drops of boiling water that can leave marks or stains. In these cases, the Anti-drip system automatically activates to prevent vaporization, so that you can iron the most delicate fabrics without risk of spoiling or staining them.

DRY IRONING

To iron without steam leave the steam selector on position “0”.

SPRAY FUNCTION

Make sure that there is water in the reservoir. Press the spray button slowly (for a dense spray) or quickly (for a vaporized spray).

WARNING: for delicate fabrics, we recommend moistening the fabric beforehand using the spray function, or putting a damp cloth between the iron and the fabric.

To avoid staining, do not use the spray on silk or synthetic fabrics.

CLEANING

Please note: before cleaning the iron in any way, make sure that the appliance plug is not connected to the socket.

Any deposits, starch residue or size left on the plate can be removed using a damp cloth or an unabrasive liquid detergent.

Avoid scratching the plate with steel wool or metallic objects.

The plastic parts can be cleaned with a damp cloth then wiped over with a dry cloth.

SELF CLEANING


The self-cleaning feature cleans inside the plate, removing impurities. We recommend using it every 10-15 days. Directions:

- Fill the reservoir up to the maximum level indicated and set the steam selector to "0"
- Set the thermostat knob to the maximum temperature and wait for the light to turn off.
- Pull the plug out of the socket and hold the iron horizontally over the sink.
- Hold the cleanout button setting until all the boiling water, steam, impurities come out.
- When the soleplate has cooled down, you can clean it with a damp cloth.

HOW TO PUT IT AWAY

- Disconnect the plug of the iron from the socket.
- Empty the reservoir by turning the iron upside down and gently shaking it.
- Leave the iron to cool down completely.
- Always put the iron away in a vertical position.

GET TO KNOW YOUR EXTREME STEAM™ 1875 WATT IRON (MODEL IR2342C)



LIMITED ONE-YEAR WARRANTY (CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below, together with your purchase receipt and \$7.50 for postage and handling. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

SERVICE CENTRE:

Conair Consumer Products ULC
100 Conair Parkway, Woodbridge, ON L4H 0L2.
1-855-926-6247

©2017 Conair Consumer Products Inc.
www.conaircanada.ca

Consumer Call Centre E-mail :
Consumer_Canada@Conair.com

17CN029454

IB-15152

EXTREMESTEAM™

WITH NANO TITANIUM SOLEPLATE TECHNOLOGY



Have a Question?

Please do not return this product to the retailer.

Call Us First!

Our customer service and product experts are ready to answer ALL your questions.

Please call our TOLL-FREE customer service number at: 1-855-926-6247 or visit us online at www.conaircanada.ca

CONAIR®

For your safety and enjoyment of this product, always read the instruction booklet carefully before using.

**IR2342C
Instruction Booklet**