

Figure 1




Figure 2

STORAGE


Disconnect from electrical outlet. **BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED.** Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged. Handle cord carefully for longer life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord or a short circuit. To store mirror, coil cord loosely.

MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed. If cleaning becomes necessary, disconnect the appliance from the power source and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry. If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

WARNING:
IF YOU THINK THE
POWER IS OFF
WHEN THE SWITCH
IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically alive even if the switch is OFF? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

Public Service AD from Association of Home Appliance
Manufacturers and Underwriters Laboratories, Inc.

LIMITED ONE YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below, together with your purchase receipt. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

SERVICE CENTRE :

CONAIR CONSUMER PRODUCTS ULC

100 Conair Parkway, Woodbridge, Ont. L4H 0L2

Printed in China

1-855-926-6247

Visit our Web site: www.conaircanada.ca

Consumer Call Centre E-mail:

Consumer_Canada@Conair.com

©2020 CONAIR CONSUMER PRODUCTS ULC

20CN074072

IB-16884

renew • refresh • revive

true glow™

Variable lighted makeup mirror for a gentle glow.



HAVE A QUESTION?

Please do not return this product to the retailer.

CALL US FIRST!

Our customer service and product experts are ready to answer **ALL** your questions. Please call our **TOLL-FREE** customer service number at :

1-855-926-6247

Or visit us online at

www.conaircanada.ca

Use & Care Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Model TGBE104XC

IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL FURNISHING, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

DANGER— TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS FURNISHING FROM THE ELECTRICAL OUTLET BEFORE CLEANING OR SERVICES AFTER CLEANING.

WARNING— TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.
7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
9. To disconnect, turn all controls to the 0 position, then remove plug from outlet.

10. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
11. Do not use on a soft surface such as a bed, where openings may be blocked.
12. Turn switch to 0 position and unplug cord before replacing light bulbs.
13. Do not place or store this furnishing where it can fall or be pulled into a tub or sink.
14. If this furnishing falls into water, unplug it immediately. Do not reach into the water.
15. Never use while sleeping.
16. Do not use bulb greater than 20 watts. Use in any 120 volt, 60 hertz AC electrical outlet (ordinary house current). Do not use it in any other electrical outlet.
17. To protect against electrical hazards, do not use while bathing or in the shower.
18. Unplug the mirror from outlet before cleaning. Do not leave mirror unattended when it is plugged in.
19. Never operate this furnishing with the air openings blocked. Keep the air openings free of lint, hair and the like.

FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this mirror has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician to install the proper outlet. Never use with an extension cord unless plug can be fully inserted. Do not change the plug in any way.

CAUTION: BE SURE DIRECT SUNLIGHT DOES

NOT STRIKE MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.

1. Your circular lighted makeup mirror will swivel so that you can use either the standard view or the magnified view located on the opposite side.
2. Plug cord into any standard 120 volt wall outlet. To turn on lights, simply turn the dial on the base to desired light setting.
3. After use, always turn switch to the 0 position.
4. The beauty and design of this mirror complements any decor. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see STORAGE section for detailed information.

SPECIAL FEATURES

This lighted makeup mirror uses incandescent light bulbs with special coating, simulating lighting in three different settings: home, office and day.

TO REPLACE BULB

CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB.

NOTE: Do not use a bulb greater than 20 watts. Contact the Conair service center at 1-855-926-6247 for replacement bulb information (ask for replacement #RP3435B).

1. Remove the two screws located on each side of the mirror. (Fig. 1)
2. Carefully lift 0 the top half of the housing from the bottom half that is affixed to the stand.
3. Unscrew the old bulb and replace with the new bulb. (Fig. 2))
4. Carefully replace the top housing half after locating and aligning the screw holes to the bottom half. If the holes don't line up, turn top half of mirror 180°.
5. Insert two screws into screw holes and tighten.

CAUTION:
TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

CAUTION:
RISK OF FIRE, USE ONLY
20 WATTS MAXIMUM 120
VOLT; TYPE T BULBS.

**DISCONNECTED FROM THE
SUPPLY CIRCUIT BEFORE
SERVICING OR CLEANING.**

DO NOT SUBMERSE.

**MODEL: TGBE104XC
RATING: 120V AC
60Hz 40W,0.33A**