

- Flammable. Contains pressurised butane gas.
- Do not use near fire or flames, including CERAMIC CURLING IRON cigarettes professional high-temperature ceramic coated curling
- Protect from sunlight and do not expose to temperatures over 122°F (50°C).
- Do not pierce, puncture or incinerate the butane cartridge even after it is empty.
- If using aerosol sprays or flammable liquids such as hairspray, allow at least 5 minutes before igniting the curling iron to let flammable vapours disperse.
- When igniting the curling iron, hold it away from hair and clothing. Do not ignite while curling iron is in the hair.
- Do not cover the curling iron with the hand while igniting
- Do not leave unattended while switched on.
- Careful adult supervision is required when the appliance is used on or near children or some disabled persons.
- Keep out of the reach of children.
- Allow the appliance to cool before storing away.
- Do not place the appliance on any heat sensitive surfaces whilst in operation.
- Do not immerse the appliance in water or other liquids. Do not allow to become wet.
- This appliance should only be used as described within this instruction booklet. Please retain for reference.

FEATURES:

noticeable signs of damage, or if the appliance High-Temperature Ceramic Coated Barrel

has been dropped. In the event of damage Cool Tip contact the Conair Service Centre (refer to the

Always inspect the appliance before use for

Warranty Section for further information)

iron for use at home or on the move.

through the hair for a perfect finish.

The new Cordless Butane curling iron by Conair® is a

This high-temperature portable ceramic coated curling

iron has a flawlessly smooth surface that glides

- Cordless
- Protective Heat Shield
- Conair[®] Thermacell[®] butane cartridges

INSTRUCTIONS FOR USE

To insert or change the butane cartridge

- Remove the base of the curling iron handle.
- Remove the cap from the butane cartridge.
- Place the cartridge into the handle, the top inserted first.
- Twist the cartridge clockwise and screw in place.
- Replace the handle base.

TO SWITCH THE CURLING IRON ON

- Push the ON switch and wait for approximately 5 seconds.
- Depress the start switch on the handle of the curling iron several times.
- The curling iron should now begin to heat up.
- Wait for 8 to 10 minutes, the curling iron is now ready for use.

CURLING

For best results

 Section dry hair evenly. Pressing the automatic curl release, place curling iron midway up the hair section. Release automatic curl release to hold hair in place. Gently slide curling iron down to hair ends.

Wind the hair up as far as you want it curled. For tighter, bouncier curls, roll less hair. For looser, free flowing curls, roll more hair.

IMPORTANT: Take care to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.

- Repeat as necessary.
- Allow the hair to cool before combing through.
- After use push the OFF switch, allow the appliance to cool and replace the protective heat shield.

AFTER CURLING

At the end of curling, push the OFF button and replace the protective heat shield, taking care not to allow the hot barrel of the curling iron to come into contact with the skin.

TO CHECK LEVEL OF BUTANE CARTRIDGE

Check the level of fuel left in the butane cartridge by looking at the clear base of the cartridge while in a horizontal position (see figure 1). If a cell is empty replace with a new Conair® Thermacell® butane cartridge.

Figure 1



LIMITED THREE YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 36 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below together with your sales slip and \$5.50 for postage and handling. In the absence of a receipt, the warranty period shall be 36 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 36 MONTH DURATION OF THIS WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL. INCIDENTAL. OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights which vary from province to province.

SERVICE CENTRE:

Conair Consumer Products ULC 100 Conair Parkway. Woodbridge, ON, L4H 0L2,

1-800-472-7606

©2014 Conair Consumer Products UI C www.conaircanada.ca

IB-12634

Consumer Call Centre F-mail Consumer Canada@Conair.com www.conaircanada.ca

CORDLESS BUTANE

3/4" CERAMIC HIGH HEAT CORDLESS CURLING IRON



Please allow styling iron to heat up for 8 to 10 minutes before use in order to acheive optimal styling results.

Have a Question? Please do not return this product to the retailer.

Call Us First!

Our customer service and product experts are ready to answer ALL your questions. Please call our TOLL-FREE customer service number at: 1-800-472-7606 or visit us online at www.conaircanada.ca

Instruction & Styling Guide

For your safety and continued eniovment of this product, always read the instruction book carefully before using.

MODEL TC700WC



13CN146126