

This message about...

NTERRUPTERS

...can save a life!

IF YOU MUST USE YOUR HOT AIR STYLER IN THE BATHROOM, INSTALL A GFCI*NOW! Your local electrician can help you decide which type is best for you-a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCI's in the bathrooms, garages, and outdoor outlets of all new homes.

WHY DO YOU NEED A GFCI? Electricity and water don't mix. If your HOT AIR STYLER falls into water while it's plugged in, the electric shock can kill you...even if the switch is



"off." A regular fuse or circuit breakwon't protect under these circumstances. A GFCI offers you far greater protection.

A GFCI can save your life! Compared to that, the price is small! Don't wait... install one now!

*GFCI is a sensitive device which reacts immediately to a small electric current leak by stopping the electricity flow.

USER MAINTENANCE

Your appliance is virtually maintenance-free. For proper performance, the appliance must be kept clean. Blocked or clogged air intake vents will cause the appliance to overheat. When cleaning is needed, unplug the cord and clean dust and lint from air intake openings with a small brush attachment. The outer surface of the appliance should be wiped clean with a cloth only. If abnormal conditions occur, unplug the appliance, allow it to cool and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the appliance. Damage will occur at the high-flex point of entry into the appliance, causing it to rupture and short circuit.

Inspect the cord frequently for damage. STOP USE IMMEDIATELY if damage is visible or if unit stops or operates intermittently.

STORAGE - Important

When not in use, your appliance should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WARNING: IF YOU THINK THE **POWER IS OFF WHEN** THE SWITCH IS OFF YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

A Public Service Ad from the Association of Home Appliance anufacturers and Underwriters Laboratories, Inc.

- pull away from the hot air brush.
- er debris from the filter.
- Using a soft brush, clean any hair and
- Replace the rear filter by aligning the groves and turn clockwise until the rear filter has clicked back into position.

SERVICE CENTRE:

CONAIR CONSUMER PRODUCTS ULC 100 Conair Parkway Woodbridge Ontario, L4H 0L2 ©2020 CONAIR CONSUMER PRODUCTS ULC For more information on any Conair product call: 1-855-926-6247 Visit our Web site: www.conaircanada.ca

Consumer Call Centre E-mail: Consumer_Canada@Conair.com

IB-16671 19CN035051

INSTRUCTIONS FOR USE

- · If you have long or thick hair, you may find it quicker and easier to use a hairdryer first, to rough dry your hair and remove the excess moisture. For added volume, turn your head upside down as you dry.
- . Once the hair is 80% dry, you should start to create your style using the styler.

MAXIMUM VOLUME AND BODY

- 1) Start by sectioning the hair.
- 2) To turn the appliance on, slide the on/off switch to the correct heat setting for your
- 3) Place the appliance into the hair, close to the roots and brush through the section to remove any tangles.
- 4) For added root lift, hold the brush in place at the root for a few seconds.
- Repeat as necessary.
- 6) After use, switch off and unplug the appliance.
- 7) Allow to cool before storing away.

INFINITI**PRO**

FRIZZ FREE 11/2 IN. TITANIUM **HOT AIR BRUSH**

-TITANIUM CERAMIC-



Have a Question?

Please do not return this product to the retailer. Call Us First!

Our customer service and product experts are ready to answer ALL your questions.

Please call our TOLL-FREE customer service number at: 1-855-926-6247 or visit us online at www.conaircanada.ca

> Model BC600C Instruction Booklet

GET TO KNOW YOUR HOT AIR SPIN STYLER



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS **BEFORE USING** KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

- 1. Always "unplug it" immediately after us-
- 2. Do not use while bathing or in a shower.
- 3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 4. Do not place in, or drop into, water or
- 5. If an appliance falls into water, "unplug it" immediately. Do not reach into the water.

WARNING- To reduce the risk of burns, electrocution, fire, or injury to persons:

- 1. This appliance should never be left unattended when plugged in. Do not pull, twist, or wrap line cord around appliance.
- 2. Close supervision is necessary when this appliance is used by, on, or near children
- 3. Use this appliance only for its intended use as described in this manual. Do not

- use attachments not recommended by the manufacturer.
- 4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged or dropped into water. Return the appliance to an authorized service centre for examination and repair.
- 5. Keep the cord away from heated surfaces. Do not wrap the cord around appli-
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- 7. Never use while sleeping.
- 8. Never drop or insert any object into any opening or hose.
- 9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10. Do not use an extension cord with this appliance. 11. Do not direct hot air toward eyes or other
- heat sensitive areas. 12. Attachments may be hot during use. Al-
- low them to cool before handling. 13. Do not place appliance on any surface while it is operating.
- 14. Do not use with a voltage converter.
- 15. While using this appliance, keep your hair away from the air inlets.
- 16. This appliance is not a toy. Keep away from children.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This appliance is intended for household use. Use on Alternating Current (60 hertz) only. Standard curling appliances are designed to operate at 110 to 125 volts AC.

This appliance has a polarized plug (one blade is wider than the other.) As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

GETTING STARTED

This hot air brush is perfect for adding gorgeous volume and shine to styles. The large titanium ceramic barrel gives fullness and body as you style whilst the soft bristles create ultimate shine and smoothness to hair.

ADVANCED IONIC TECHNOLOGY

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution contribute to a build-up of static electricity in the hair. Even brushing and towel drying the hair, can increase these levels causing the surface of the cuticle to become rough.

Consequently, hair may have a dull appearance. Also high levels of static charge cause hair to become "fly-away" and difficult to

The ion generator produces a stream of negative ions which act to neutralise the static charge, smoothing the scales on the cuticle for shiny, smooth and manageable hair so you can achieve your desired style easily.

HEAT SETTINGS

There are 2 heats plus a cool setting. Use the high heat setting for initial drying, and the low heat setting as hair begins to dry and for styling. Use the cool setting to set the style for long lasting results. To select the cool setting, slide the on/off switch to the first position, the second position for the low heat and the third position for the high heat.

TITANIUM CERAMIC TECHNOLOGY

The barrel of this premium hot brush is coated with a combination of the best materials for styling. A fusion of titanium and ceramic evenly distributes heat to gently style and protect hair from damaging hot spots. Hair wraps easily over the surface of this ultrasmooth barrel. Barrel is exceptionally easy to clean, and you'll discover this combination of technologies leaves your hair silky smooth.

CLEANING THE FILTER

LIMITED THREE YEAR WARRANTY

Conair will repair or replace, at our option, your

appliance free of charge for 36 months from

the date of purchase if the appliance is

To obtain service under this warranty, return

the defective product to the service centre

listed below together with your sales slip

and \$7.50 for postage and handling. In the

absence of a receipt, the warranty period

shall be 36 months from the date of

ANY IMPLIED WARRANTIES, OBLIGATIONS,

OR LIABILITIES, INCLUDING BUT NOT LIM-

ITED TO THE IMPLIED WARRANTY OF

MERCHANTABILITY AND FITNESS FOR A

PARTICULAR PURPOSE, SHALL BE LIMITED IN

DURATION TO THE 36 MONTH DURATION OF

IN NO EVENT SHALL CONAIR BE LIABLE

FOR ANY SPECIAL, INCIDENTAL, OR CONSE-

QUENTIAL DAMAGES FOR BREACH OF THIS

OR ANY OTHER WARRANTY, EXPRESS OR

This warranty gives you specific legal rights,

and you may also have other rights which

manufacture.

THIS WARRANTY.

IMPLIED, WHATSOEVER.

vary from province to province.

defective in workmanship or materials.

- Ensure the hot air brush is switched off, unplugged and cool.
- Holding the handle of the hot air brush, grip the rear filter and turn anticlockwise, as far as the rear filter will turn and
- 3. Use a soft brush, clean any hair and oth-
- other debris from the filter.