USER MAINTENANCE INSTRUCTIONS

CARING FOR YOUR CONAIR FOR HER™ FACIAL

- 1 After each use rinse brush head and wine the brush handle with a damp cloth to remove any oils or lotions used during treatment.
- 2. Clean unit thoroughly each week by rinsing under warm, soapy water to help remove oil and lotion buildup, wipe with a dry cloth and store unit in its box or in a clean, dry place.
- 3. Remove brush heads once a week and rinse under warm, soapy water to remove residue accumulated during treatment. Allow brush heads to air-dry. Store in a clean, dry place.
- 4. Do not use abrasive cleaners for cleaning.
- 5. Do not put unit in dishwasher for cleaning.

Note: It is recommended to replace the brush attachments every 90 days, as the bristles wear over time and lose their efficacy.

TROUBLE-SHOOTING GUIDE

THE BRUSH IS NOT WORKING.	Make sure the contacts in the unit are clean. See user maintenance instructions for cleaning procedure.
	Make sure the batteries are installed properly.
THE BRUSH OPERATES AT SLOW SPEED.	Replace the batteries.
THE BRUSH HEAD VIBRATES OR FALLS OFF DURING USE.	Make sure the brush head is snapped on properly.
	2. Replace the brush head.

1. Always purchase the correct size and grade of battery most suitable for the intended use.

DIRECTIONS FOR BATTERY USE

- 2. Replace all batteries of a set at the same time.
- 3. Clean the battery contacts and also those of the device prior to battery installation.
- 4. Ensure the batteries are installed correctly with regard to polarity (+ and -).
- 5. Remove batteries from equipment which is not to be used for an extended period
- 6. Remove used batteries promptly.
- 7. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

LIMITED ONE YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below, together with your purchase receipt. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL. INCIDENTAL. OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

SERVICE CENTRE:

CONAIR CONSUMER PRODUCTS ULC 100 Conair Parkway Woodbridge, ON L4H 0L2 ©2021 Conair Consumer Products ULC

For more information on any Conair product call: 1-855-926-6247 Visit our Web site: www.conaircanada.ca Consumer Call Centre E-mail: Consumer_Canada@Conair.com

21CN079793

IB-17364

facial kit WATER-RESISTANT BATTERY-OPERATED Have a Question? Please do not return this product to the retailer. Call Us First! Our customer service and product experts are ready to answer ALL your questions Please call our TOLL-FREE customer service number at: 1-855-926-6247 or visit us online at www.conaircanada.ca Instructions for Care and Use

IMPORTANT SAFETY **INSTRUCTIONS**

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING THE FACIAL BRUSH

- 1. Close supervision is required when this product is used on, by or near children or people with certain disabilities.
- 2. Use product only for its intended use as described in this instruction booklet. Do not use attachments not recommended by the manufacturer.
- 3. Keep the unit away from heated surfaces.
- 4. Never use while sleeping or drowsy.
- 5. Do not use outdoors or where oxygen is being administered.
- 6. Never operate if the product is damaged.
- 7. Not for use by children.
- 8. Water resistant: can be rinsed in a shower, but not submerged.

The CONAIR FOR HERTM Facial Brush handle has no serviceable parts. Call 1-855-926-6247 for instructions to purchase replacement brush heads.

SENSITIVITY AND CAUTIONS SPECIAL CAUTIONS FOR DELICATE AREAS

The CONAIR FOR HERTM Facial Brush is a face cleansing device that is intended to help you get clean and healthy-looking skin. The CONAIR FOR HERTM Facial Brush is not a medical device and is not intended to be used to treat any medical conditions such as acne.

If you are under a doctor's care for any skin condition or if you think you have very sensitive skin, please consult your physician before use.

We recommend starting on the LOW setting and increasing speed to HIGH setting depending on how your skin reacts to treatment. If rash or irritation occurs, stop use.

We recommend not sharing the brush heads; each user should have their own brush head.


Do not use with exfoliation creams with rough or jagged particles.

Removing makeup can cause the brush head to discolor. This will not affect performance and the brush head can be used for the entire recommended life of 90 days.

If you experience any pain or discomfort during use, stop using and consult your physician.

Moisten your face and apply cleanser. Also apply a small amount of cleanser to the moistened brush head. Do not apply pressure with the brush to the face; let the oscillation perform the cleansing. When finished, rinse with water and dry skin with a clean towel

CONAIR FOR HER™ FACIAL **BRUSH FEATURES**



TWO SPEED OPTIONS

The two speeds available on your CONAIR FOR HERTM Facial Brush allow you to customize your facial cleansing routine to suit your individual needs.

ATTACHMENTS

3 CLEANSING BRUSHES: Gentle cleansing and exfoli-

Note: Your CONAIR FOR HERTM Facial Brush may only include certain attachments. See retailer for replacement units or call 1-855-926-6247 or visit www.conaircanada.ca



3 CLEANSING BRUSH

mend to replace attachments every 3 months.

OPERATING INSTRUCTIONS

NOTE: The CONAIR FOR HERTM Facial Brush operates on 2 AAA batteries (not included).

- 1. Remove the battery cover from the unit by moving the lever clockwise until the battery door is
- 2. Install 2 AAA batteries (not included) as per the markings in the battery compartment.
- 3. Replace the cover and move the lever counterclockwise until the battery door is firmly
- 4. Select the desired attachment and push it down onto the mounting post until firmly in place.

STARTING THE FACIAL BRUSH AND SELECTING THE SPEED

Press the ON/OFF button 1 time for LOW setting and 2 times for HIGH setting.

STOPPING THE FACIAL BRUSH

Press the ON/OFF button 3 times to stop the unit.

ATTACHING AND REMOVING ATTACHMENTS To attach, hold the brush by the rim and attach over

mounting post until it firmly snaps into place. To remove, hold the rim and pull off.

6 FACIAL CLEANSING **ZONES**



FACIAL BRUSH 1. Wet your face and apply sufficient cleanser.

Also apply a small amount of cleanser to the wet brush head.

FCB4 - ALL MODELS

INSTRUCTIONS

FOR USING THE

- 2. Select attachment and attach to power handle.
- 3. Turn the brush on and select desired speed. We recommend starting on LOW and increasing speed depending on how your skin reacts to
- 4. Do not press the brush hard against your skin as it will reduce the motion and effectiveness. Keep the brush in light contact and flush against the skin.
- 5. Move the brush in a slow circular motion around your face. NOTE: Do not apply treatment close to the eyes to avoid risk of injury.
- 6. When finished, rinse with water and dry your skin with a towel.

NOTE: USE FOR 10 SECONDS AT EACH LOCATION